

HOW TO APPLY









1. PREPARE

- Not recommended for areas continually submerged in water.
- Wash/scrub with soapy water into damage, then rinse with clean water. Allow to fully dry in sun or accelerate dry with a hairdryer.
- Rotate/shake the tube for 30 seconds for even consistency.

2. APPLY

- For plastic or aluminum surfaces, apply a thin coat of MagicEzy 'MegaFusion' Primer/Sealant and allow 2 hours to cure (at 70°F/20° C).
- APPLY and overfill the damage, whilst holding a tissue in your spare hand.

3. LEVEL

• LEVEL at 90°. A gentle touch is required (as if the 'LEVEL' is floating on air).

4. TRIM

• Clean 'Level' with the tissue then TRIM smears around the repair (not the repair itself). Repeat TRIM if necessary. Avoid excessive tampering.

DRYING time varies depending on temperature. FAST DRY using a hot hair dryer for 3 minutes + 30minutes cool down. NORMAL DRY 2 hours (at 70°F/20° C). It will harden overnight and achieve maximum strength and adhesion after 14 days. A second application of 9 Second Chip Fix may be required.

DEEP DAMAGE Apply in $\frac{1}{4}$ inch (6mm) layers and allow to DRY for 2 hours at 70°F/20° C or 3 minutes using a hairdryer (plus 30mins cool down) then apply the next layer.

REPAIR SECRETS

Color match?

Mix two or more colors on a clear plastic wrap. View new color when placed over the surface.

How do I apply on vertical surfaces?

To prevent slump or for a FAST dry time, use a hairdryer for 3 minutes to form a skin.

How do I get a gloss finish?

MagicEzy 9 Second Chip Fix dries matte. Add a thin top coat of MagicEzy Hairline Fix for gloss.

How do I apply in hot/cold weather?

In temperatures above 90°F (30°C) lay a damp towel over the area until hand temperature is reached. Below 60°F /15°C, set with hairdryer for 3 minutes.

FINISH: MATTE



We guarantee that when MagicEzy products are applied according to instructions, the repair will last for 3 years or your money back.

